




CaseCore End Seal Closed and Open Installation Guide



Ultimate Solutions.
Intelligent Delivery.

CASECORE END SEAL OPEN INSTALLATION GUIDE



Step 1: Prepare the seal

Place the CaseCore End Seal Open on a clean, dry surface with the tapered bonding strips facing upwards.

Important: Ensure the bonding surfaces are clean, dry and free from grease or contaminants.



Step 2: Apply the adhesive

Apply a thin, even layer of the supplied adhesive to both bonding strips (approximately 30 mm wide).

Allow the adhesive to cure for 10–15 minutes until it feels dry to the touch while remaining tacky. A simple finger test can be used to confirm the correct curing time.



Step 3: Position the End Seal

Wrap the CaseCore End Seal Open around the carrier pipe, ensuring the larger diameter of the seal faces towards the casing pipe.



Step 4: Align the two bonding strips

Carefully align the two bonding strips and press them firmly together to create a secure joint.

Installation Tip: For the best bond, use a pressure roller or a small wooden block to apply even pressure along the bonded seam using an up-and-down rolling motion.

CASECORE END SEAL CLOSED

Step 5: Position the End Seal



Slide the CaseCore End Seal Closed over the carrier pipe and pull the larger end onto the casing pipe until it is correctly positioned.

Secure the larger end of the seal to the casing pipe using the supplied stainless steel fastening strap.



Step 6: Secure the carrier pipe end

Tuck the smaller end of the seal neatly around the carrier pipe and fasten it securely using the second stainless steel fastening strap.

Ensure both fastening straps are tightened evenly to achieve a secure, wrinkle-free seal.

WELLINGTON

17 Raiha Street, Porirua

AUCKLAND

3/68 McLaughlins Road, Wiri

P 0800 473 100

E sales@upg.net.nz

W upg.nz

